



- Change Item
- 1) DB7 RC3--RA1(12)
 - 2) RS RC5--RA0(13)
 - 3) sensor outputVo RA4--RC3/AN7(7)
 - 4) if change PIC16F1705 then sensorVo RC5(5)
 - 5) setting OPamp software

Sheet: /
File: Dust_Meter.sch

Title:

Size: A4 Date:
KiCad E.D.A. kicad 4.0.1--stable

Rev:
Id: 1/1